YELLOW HORNET

www.yellowhornetmfg.com

Lawn Mower Blade Sharpener



OPERATING INSTRUCTIONS

OPERATING INSTRUCTIONS FOR YELLOW HORNET BLADE SHARPENER

WARNING: ALWAYS WEAR EYE PROTECTION

When Installing Grinder Motor:

The Alignment Decal will show correct alignment.

When Installing Grinder motor there will be a small twist so the back side will be closer to blade rest than front side.

DO NOT Align Grinder Disc parallel with Blade Rest.


Have approximately 1/4" less gap at the rear than the front of grinding disc.

Position Grinder Disc Appr. 1/2 to 3/4 " above blade rest.

Correct Sharpening Procedure:

Position blade firmily on blade rest aligining the cutting edge with grinding wheel as shown in illustration.

Lowering the blade and pull towards you when sharpening. Continue this procedure until desired cutting edge is obtained.



Picture demonstrates the angle and method to sharpen.

Recommend using a 50/60 grit High Performance Abrasive (Paddle/Flap) sanding disc.

ANY FURTHER QUESTIONS CONTACT: yellowhornetmfg@sbcglobal.net

For more set up and operating procedures go to www.youtube.com and Search for "Yellow Hornet Blade Sharpener"